


HOW TO MEASURE



- Using a tailor's measuring tape, accurately measure your FC and HC.

HC = Head Circumference

Measure above the eyebrows, just above the ears, and over the occipital bone.

FC = Face Circumference

Measure from the top of the head down to below the throat, passing in front of the ears.

- Once you have the measurements, cross-check them with the table below to determine the best-fitting helmet for you between Zenith X2 and Zenith X2 Max.

HELMET SIZE RANGE



ZENITH X2




SIZE: Adjustable – from 52 to 63 cm



ZENITH X2 MAX



SIZE: Adjustable – from 60 to 66 cm



SIZE CHART

		HC Head Circumference (cm)								
		52	54	56	58	60	62	63	64	66
FC Face Circumference (cm)	58	X2	X2	X2	X2	X2	X2	X2	/	/
	62	X2	X2	X2	X2	X2	X2	X2	/	/
	66	X2	X2	X2	X2	X2 / X2 MAX	X2 / X2 MAX	X2 / X2 MAX	X2 MAX	X2 MAX
	70	X2	X2	X2	X2	X2 / X2 MAX	X2 / X2 MAX	X2 / X2 MAX	X2 MAX	X2 MAX
	74	X2	X2	X2	X2	X2 / X2 MAX	X2 / X2 MAX	X2 / X2 MAX	X2 MAX	X2 MAX
	78	/	/	/	/	X2 MAX	X2 MAX	X2 MAX	X2 MAX	X2 MAX
	82	/	/	/	/	X2 MAX	X2 MAX	X2 MAX	X2 MAX	X2 MAX
	86	/	/	/	/	X2 MAX	X2 MAX	X2 MAX	X2 MAX	X2 MAX
	87	/	/	/	/	X2 MAX	X2 MAX	X2 MAX	X2 MAX	X2 MAX

The result of the measurement comparison provides a guideline for selecting the most suitable helmet model.

Watch the video to explore the wide size range of the ZENITH X collection.

